


1766

INSTRUCTION MANUAL FOR SEWING MACHINE



WHITE

POLARIZED PLUGS CAUTION

This product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact an electrician to replace the obsolete outlet. Do not defeat the safety purpose of the polarized plug.

WHITE SEWING MACHINE COMPANY

Record in space provided below the Serial No. and Model No. of this appliance.

The Serial No. is located on Bed Plate.

The Model No. is located on Rating Plate.

Serial No. _____.

Model No. _____.

Retain these numbers for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic safety precautions should always be followed, including the following:

Read all instructions before using (this sewing machine)

DANGER To reduce the risk of electric shock:

An appliance should never be left unattended when plugged in. Always unplug this appliance from the electric outlet immediately after using and before cleaning.
Always unplug before relamping, Replace bulb with same type rated 15 watts.

WARNING To reduce the risk of burns, fire, electric shock, or injury to persons:


1. Do not allow to be used as a toy. Close attention is necessary when this appliance is used by or near children.
2. Use this appliance only for its intended use as described in this manual. Use only attachments recommended by the manufacturer as contained in this manual.
3. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to the nearest authorized dealer or service center for examination, repair, electrical or mechanical adjustment.
4. Never operate the appliance with any air openings blocked. Keep ventilation openings of the sewing machine and foot controller free from the accumulation of lint, dust, and loose cloth.
5. Never drop or insert any object into any opening.
6. Do not use outdoors.
7. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
8. To disconnect, turn all controls to the off ("0") position, then remove plug from outlet.
9. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
10. Keep fingers away from all moving parts. Special care is required around the sewing machine needle.
11. Always use the proper needle plate. The wrong plate can cause the needle to break.
12. Do not use bent needles.
13. Do not pull or push fabric while stitching. It may deflect the needle causing it to break.
14. Unplug the sewing machine when making any adjustments in the needle area, such as threading needle, changing needle, threading bobbin, or changing presser foot, etc.
15. Always unplug sewing machine from the electrical outlet when removing covers, lubricating, or when making any other user servicing adjustments mentioned in the instruction manual.

SAVE THESE INSTRUCTIONS

CONTENTS



Name of Parts.	1
Accessories.	2
Removing the extension table, free arm sewing.	3
Before sewing (Power supply and Sewing lamp).	4
Fitting shank and quilting seam guide. Fitting of presser feet	5
Winding the bobbin	6
Removing bobbin case and bobbin	7
Inserting bobbin into bobbin case.	7
Inserting bobbin case into shuttle race.	8
Changing needle	8
Threading upper thread & Twin needle threading.	9
Drawing up bobbin thread.	10
Changing sewing directions	10
Adjusting thread tensions	11
Regulating the presser foot pressure	12
Drop feed	12
Fabric, Thread, Needle guide	13
Sewing (pattern selector) and operation table	14
To start sewing to finish a seam	15
Straight stitch	16
Blind hemming	17
Three step zig-zag	18
Overcasting edges-binding	19
Straight stretch stitch	20
Sewing on buttons	21
Sewing in zips.	22
Button hole sewing	23
Hemming.	24
Twin needle-freehand embroidery.	25
Cleaning of race and shuttle hook.	26
Cleaning and oiling	27
Trouble shooting guide.	28

NAME OF PARTS (FRONT SIDE)



- 1 Pattern selector dial
- 2 Take up lever
- 3 Tread tension dial
- 4 Tread guide for upper
threading
- 5 Presser foot
- 6 Shuttle cover
- 7 Handle
- 8 Spool pin
- 9 Top cover
- 10 Stitch length dial
- 11 Reverse button
- 12 Face cover

(REAR VIEW)




ACCESSORIES




Bobbin




Felt



**Zigzag foot
(On machine)**




Button hole foot




Button foot




Machine Oil




Zipper foot



Button hole cutter




Screw driver



Needle


11 # 14

REMOVING EXTENSION TABLE




To convert the machine from flat-bed use to free-arm use simply remove the extension table as shown.

FREE-ARM SEWING




1. Especially useful when sewing sleeves, pants leg, tubular fabrics, etc., more easily.
2. To sew tubular, just slip the sleeve or pants leg on the free arm as shown above.
3. This sewing machine can be used as a flat bed machine, but easily converts to free arm machine by removing the extension table.

BEFORE SEWING



1. Fit the machine plug into the machine.
2. Plug the machine to the power supply.
3. Sewing speed can be varied by the speed controller.

(BE SURE TO FIT A CORRECT PLUG TO SUPPLY CORD)



1. Remove or install lamp from inside of face cover.
2. Open face cover in direction of arrow.
3. Remove lamp by unscrewing it counter clockwise.
4. Install a new bulb by screwing it in clockwise.
5. Use only a 120v , 15W (Max) "Hi-Light" brand replacement sewing machine lamp. Available from your Riccar stockist.

Important: When leaving the machine unattended, servicing, changing lamps or removing covers, disconnect from the supply by removing plug from the socket outlet.





FITTING SHANK AND QUILTING SEAM GUIDE

Raise the presser bar and fit shank as shown. (1) Insert quilting/seam guide carefully so as not to damage the holding spring. (2)


FITTING OF PRESSER FEET

Raise the presser foot. Pull the one-touch lever towards you and the foot will be released. Centre new foot under shank.


Lower shank until groove is directly above and touching the pin. Pull one-touch lever towards you and the foot will become engaged. (3, 4)




WINDING THE BOBBIN



1. Release stop motion knob.
2. Thread as shown.
3. Place bobbin onto spindle and hand-wind thread onto bobbin in an anti-clockwise direction for 5 or 6 turns. (When bobbin is filled re-tighten stop motion knob)



4. Push bobbin winder spindle against stopper, in direction of arrow, and depress foot pedal.
5. When bobbin winding is completed return spindle to its original position.




Note:

If the bobbin winding should be uneven (it is factory set) the thread guide can be raised or lowered to achieve the correct winding.


Remove the top cover and adjust with a suitable tool.

REMOVING BOBBIN CASE AND BOBBIN




1. Raise needle to its highest position and open the shuttle race cover.

Hinged latch




2. Open hinged latch of bobbin case and pull bobbin case out of machine.




3. Release the latch and bobbin will fall out easily.


INSERTING BOBBIN INTO BOBBIN CASE



1. Pull off 5cm of thread from bobbin and insert it into bobbin case as shown.





2. Guide the end of thread into slot.



Tension spring


3. Pull into slot and under tension spring and draw out about 10 cm of thread.

INSERTING BOBBIN CASE INTO SHUTTLE RACE



1. Ensure needle is at its highest position. Pulling thread to the front, open the latch of bobbin case and hold it.
2. Holding latch open, place bobbin case onto centre pin in shuttle and release latch.

CHANGING NEEDLE








1. Raise needle to its highest position.
2. Loosen needle clamp screw and remove old needle.
3. With the flat side of the needle facing away from you, insert needle as far up as it will go.
4. Tighten the needle clamp screw securely.

Note:

At the first sign of any stitching irregularity always change the needle for a new good quality one.

THREADING UPPER THREAD



Thread the machine from A to G as illustrated.

A. Through the thread guide.

B. Between the tension discs.

C. Up and into the tension spring.

D. Into the thread take-up lever from right to left.


E. Down behind the thread guide.

F. Behind the needle clamp thread guide.


G. Through the needle from front to back. Fig. 1 & 2 also illustrates threading for twin needle sewing (see page 25)

DRAWING UP BOBBIN THREAD


Hold the top thread with a slight tension in your left hand and rotate the hand wheel towards you so that the needle goes down and up again, then gently pull your thread out towards the rear and under your sewing foot and you are ready to start sewing.



CHANGING SEWING DIRECTIONS




1. Lower needle down into fabric and raise presser foot, pivot the fabric around the needle to change direction as desired.



2. Put down presser foot and start to sew.


ADJUSTING UPPER THREAD TENSION




It is only normally necessary to adjust the upper thread tension to achieve the correct balance between the upper and lower threads.

The higher the number on the dial the greater the tension.

Correct




Incorrect




ADJUSTING LOWER THREAD TENSION


Lower thread tension can be adjusted by turning the screw on the bobbin case slightly to the right (clock-wise) to increase tension, (Anti-clockwise) to the left to decrease tension.



As a general guide only, the user can achieve the correct tension for normal sewing, by carefully suspending the wound bobbin in its case by the thread. If the bobbin and case immediately fall to the ground, the tension is too loose and should be increased. The correct tension is obtained when a slight jerk of the thread causes the bobbin to drop a short distance only. If this action does not move the bobbin the tension is too tight and should be loosened until the desired effect is achieved.




REGULATING THE PRESSER FOOT PRESSURE



1. Adjust lever to desired pressure. For light fabrics use 3, for medium fabrics use 1-2, for heavy fabrics use 1.
2. Insufficient pressure may cause poor feeding, skipped stitches, or difficulty in guiding the fabric.
3. No. pressure adjustment 0 is required when darning or sewing freehand embroidery.

DROP FEED


















Lower feed dog by pushing lever, down in direction of arrow.
(No feeding of fabric)

Used when sewing on buttons, free hand embroidery, etc.



















For general sewing, raise height of feed dog by lifting lever in direction of arrow.

FABRIC · THREAD · NEEDLE · GUIDE

				Pressure of presser foot	Length of stitches		Indica- tion of tension
	Fabric	Thread	Needle		ST.	ZZ.	
				Pressure regulation 	Stitch length dial 		
Light 	Nylon	80 Cotton	11		0.5-3	0.5-3	
	Tricot	60 S. Fiber					
	Silk	50 silk					
	Wool silk	50 S. Fiber Silk	11				
Medium 	Ging ham	60-80 Cotton	11 or 14		0.5-4	0.5-4	
	Thin Jersey	60 S. Fiber					
	Gabardine	50 Silk					
Heavy 	Denim	50 cotton	14		1-4	0.5-4	
	Jersey	50 S. Fiber	14				
	Tweed	50 Silk	14				

As a general rule use shorter stitch lengths on finer fabrics and longer stitch lengths with heavier fabrics, finer thread and needles with finer fabrics and heavier thread and needles with heavier fabrics. Use special 'ball point' or 'stretch' needles on difficult stretchy fabrics.

SEWING (PATTERN SELECTOR) AND OPERATION TABLE

	Operation Sewing way	Pattern	Stitch length	Presser foot	Drop feed
1	Straight Stitch		4 0		
2	Zig-Zag		4 0		
3	Blind Hem		4 3 1 0		
	Three step-Zigzag Stitch		2 1		
4	Slant Overedge				
	Straight Stretch Stitch				
5	Button Hole		1 5 0 25		
6	Twin Needle	except button hole	4 2 0		
7	Freehand Embroidery			Not Necessary	

TO START SEWING



Important Hints.

1. Raise the take-up lever to its highest position when starting and stopping sewing.
2. Hold both threads about 10 cms to the rear of machine for the first two or three stitches.
3. Sufficient fabric should be placed under needle before lowering presser foot.
4. Depress foot/Speed control and start to sew.
5. Test the machine stitches on a scrap of fabric you plan to use, adjusting the machine for the length of stitch and tension suitable to your fabric.

Attention.

1. When turning the hand wheel manually, always turn it toward you.
2. Guide the cloth gently with your hand.
3. To prevent breaking needle always stop with the needle out of the fabric.


TO FINISH SEAM



1. Sew to the edge of seam.
2. Push the reverse button and sew in reverse for about 2 – 3 cms.
3. Raise needle to its highest position.
4. Lift presser foot and pull out the fabric to rear of machine.
5. Cut threads, as shown, on the thread cutter.

STRAIGHT STITCH

While "2" or "3" on the dial gives a suitable stitch length for ordinary purposes, the stitch length varies with the weight of fabric, thickness of thread and purposes, the stitch length varies with the weight of fabric, thickness of thread and purpose of sewing. Generally speaking, the finer the fabric, the finer the thread and shorter the stitch length; the heavier the fabric, the thicker the thread and longer the stitch length.



At "0" the fabric will not move ahead, and the needle will keep piercing the same point.

BLIND HEMMING (optional)


Fold the fabric as illustrated with the "wrong" side facing upwards.(1) .

Place the folded fabric under the foot as shown.

Turn the hand wheel towards you by hand, until the needle swings over to the far left. It should then just pierce the fold of the fabric. (2) If it does not, then adjust the position of the fabric.

Once the correct position of the fabric has been set, position the "guide" of the foot (3) up against the fold (2) by turning the nut (4).

Proceed to sew carefully feeding the fabric to ensure it retains the correct position against the guide. (3) Note: Some practice will be needed to obtain the best results. Always test the stitch first on a spare piece of fabric.




THREE STEP ZIG-ZAG

The three step zig-zag stitch has a wide range of sewing applications, such as patching, darning, repairing tears, mending, sewing on elastic and lace, oversewing edges etc. on a wide range of fabrics.

The illustration shows patching, where the stitches are to the edge of the patch and a tear, where the stitches go firstly over the centre of the tear and then to either side but overlapping slightly on the first row.

The stitch length can be reduced until the stitches are very close together. This will give a stronger finish for most repairing operations.




OVERCASTING EDGES

For thicker fabrics




Both these stitches are designed to overlock the edge of a fabric. When the needle is at its extreme right position, allow it to just pass over or just pierce the edge of the fabric according to the effect you require.

Using the overcasting foot will prevent puckering of thin fabrics.




BINDING



To sew fabrics edge to edge select the multi zig-zag stitch.


STRAIGHT STRETCH STITCH

The straight stretch sews two stitches forward and one stitch backwards, thereby giving "triple" strength. Use it for stretch fabrics and for areas of "stress" where a strong stitch is required.



SEWING ON BUTTONS


1. Fit darning plate as described on page 12.
2. Use button presser foot and attach firmly.
3. Place button between presser foot and fabric and lower presser foot.
4. Manually turn hand wheel towards you ensuring that the needle enters into both holes of button without obstruction.
(Increase or decrease width setting).
5. Sew about 7 stitches.
6. Pull both threads to the underside and tie together.



SEWING IN ZIPS

Fit the Zipper foot. The Zipper foot can be moved to the left or right. (2) To sew on the right hand side of the zipper, move foot over to the right as illustrated and reverse the procedure to sew the left hand side of the zipper. (3)

To move the "zip slider" out of the way, leave needle in the fabric, raise foot and slide it behind the foot. Lower the foot and continue.



BUTTON HOLE SEWING

Fit the button hole foot.


Set the stitch length dial within the green marking to achieve the correct density (closeness) of satin stitch. (1) Sew in the sequence illustrated (1) selecting patterns 18, 19, 20 and 19 again.

USER TIPS


Always sew a sample buttonhole on some spare fabric as settings will change according to the fabric used. For very thin, stretchy or other difficult fabrics, try using interfacing (vilene) or tissue or other paper underneath the fabric to aid machine feeding.

Always use the Buttonhole foot using its calibrated markings to measure the buttonhole length. On suitable fabric, a corded buttonhole can be sewn taking care that the zig-zag stitches of the buttonhole oversew the cord. (2)


Carefully cut between the sides (beads) of the buttonhole with the seam ripper using a pin through the end bar tack (2) to prevent the seam ripper going too far. The top tension may be reduced to achieve a better looking buttonhole.



HEMMING (optional)




1. Raise the foot and the needle to its highest position. Replace the foot with the hemmer foot.
2. Fold over the fabric edge by about 3mm and place it under the foot. Secure the folded edge with a few stitches. Take out the workpiece and draw the hem into the hemmer foot by pulling the threads.



3. Lower the foot and sew the hem.
4. During sewing, fold the fabric to the left a little and allow it to run into the hemmer foot.
5. Make sure that the fabric does not move under the right half of the foot. The fabric must be fed into the scroll of the hemmer sufficiently so that the workpiece edge runs freely through the groove under the foot.

Only suitable materials can be used and some practice may be necessary to achieve best results.

TWIN NEEDLE (optional)



Thread machine as for normal sewing using both spool pins and pass the threads through the same procedure but through the eye of each needle.

NB. Sewing width should not exceed the third widest stitch width, exceeding this will result in breaking of needles.

Suitable for stitch numbers 1, 2, 3 and 13 only.


FREEHAND EMBROIDERY

In freehand embroidery, unlike mechanically controlled stitching, feeding of the fabric is done by hand without assistance from feed dogs.

Fit darning plate as described on page 12 and set stitch patterns from 1-5 as desired.

A round embroidery hoop is generally used. Use wooden or plastic hoops with an adjusting screw.

Stretch the fabric tight across the hoop and sew whilst moving the hoop to create the desired effect.




CLEANING OF RACE AND SHUTTLE HOOK


Raise the needle bar to its highest point by turning the hand wheel toward you.
Open shuttle cover.

- 1) Take out the bobbin case.
- 2) Unlock the shuttle race holder.
- 3) Release the shuttle race cover.
- 4) Take out the shuttle hook


Clean dust and gummed oil off each part with an oiled cloth. When finished cleaning, reassemble reversing the above procedure.




CLEANING AND OILING



Cleaning feed dog



Open top cover and oil points indicated.



Oil points indicated on underside of bed base.

TROUBLE-SHOOTING GUIDE

CONDITION	CAUSE	REMEDY
Top thread breaks	<ol style="list-style-type: none"> 1. Machine is threaded incorrectly. 2. Tension is too tight. 3. Thread is too heavy for needle size. 4. Needle is inserted incorrectly. 5. Thread may be caught on reel holder. 6. Needle is damaged. 	<ol style="list-style-type: none"> 1. Rethread machine and needle. 2. Reduce tension on top (smaller numbers). 3. Use larger needle. 4. Reinsert needle (flat side toward back). 5. Remove spool, rewind excess thread. 6. Insert new needle.
Lower thread breaks	<ol style="list-style-type: none"> 1. Bobbin case is not inserted correctly. 2. Bobbin case is improperly threaded. 3. Bobbin tension is too tight. 	<ol style="list-style-type: none"> 1. Reposition bobbin. Check by pulling thread. If it pulls smoothly it is correct. 2. Check for correct threading. 3. Change bobbin tension according to instructions.
Skipped stitches	<ol style="list-style-type: none"> 1. Needle is not inserted correctly. 2. Needle is damaged. 3. Wrong type of needle is used. 4. Wrong foot is used. 5. Foot pressure is wrong. 	<ol style="list-style-type: none"> 1. Reinsert needle (flat side toward back). 2. Insert new needle. 3. Match needle size to fabric and thread weight. 4. Check to see if proper sewing foot is used. 5. Check foot pressure regulation for proper setting.
Needle breakage	<ol style="list-style-type: none"> 1. Needle is damaged. 2. Needle is not inserted correctly. 3. Fabric too heavy/wrong needle size. 4. Fabric is being pulled by operator. 5. Wrong sewing foot is used. 	<ol style="list-style-type: none"> 1. Insert new needle. 2. Reinsert needle correctly (flat side toward back). 3. Match needle size to thread & fabric weight. 4. Do not pull on cloth. Check for proper foot pressure. 5. Use correct foot.
Stitching forms loops	<ol style="list-style-type: none"> 1. Needle is not threaded correctly. 2. Bobbin is not threaded correctly. 3. Needle/fabric/thread ratio is incorrect. 4. Incorrect tensions. 	<ol style="list-style-type: none"> 1. Thread needle front to back. 2. Thread bobbin according to chart. 3. Match needle size to thread & fabric weight. 4. Set correct tensions.
Seams shrink or pucker	<ol style="list-style-type: none"> 1. Foot pressure is too heavy. 2. Needle is too large for fabric. 3. Wrong stitch length is used. 4. Tension is too heavy. 	<ol style="list-style-type: none"> 1. Reduce foot pressure (smaller numbers). 2. Use smaller needle. 3. Adjust length for proper stitches. 4. Check tensions.
Irregular stitching/feeding	<ol style="list-style-type: none"> 1. Thread is of poor quality. 2. Foot pressure is too light. 3. Bobbin is threaded incorrectly. 4. Material is being pulled by operator. 	<ol style="list-style-type: none"> 1. Use quality thread! 2. Increase foot pressure (larger numbers). 3. Thread bobbin again and check for proper insertion. 4. Do not pull on fabric. Let it feed automatically.
Machine is noisy and rough	<ol style="list-style-type: none"> 1. Machine needs oil. 2. Lint and oil residue have collected in hook or on needle bar. 3. Inferior oil has been used and gums up machine. 4. Needle is damaged. 5. Machine requires servicing. 	<ol style="list-style-type: none"> 1. Oil according to instructions. 2. Clean race and hook according to instructions. 3. Clean and oil again only with fine sewing machine oil (not 3-in-1 oil). 4. Replace needle. 5. Consult your specialist dealer.